


Phase90-Classie

Partlist

R1	10k	C1	10n
R2	10k	C2	33u/16
R3	10k	C3	47n
R4	22k	C5	47n
R5	10k	C7	47n
R6	10k	C8	47n
R7	22k	C10	47n
R8	10k	C11	47n
R9	10k	C12	10n
R10	22k	C13	33u/16
R11	10k	C14	10u/50
R12	10k	ZD2	5v1
R13	22k	IC1-6	LM741
R14	22k	Q1-4	2N5952
R15	150k	R26	220k trim
R16	150k	SPEED	500kC
R17	150k		
R18	56k		
R19	150k		
R20	3m9		
R21	150k		
R22	4k7		
R23	470k		
R24	150k		
R25	1m		
R27	10k		
R28	470k		
R29	10k		
R30	470		



<http://www.circuitfx.com>

-Classic P90-